

Index

A

AC adapter
 connecting, xvii
 taking care of, xi
Advanced Power Management (APM), 2-17
applications, accessing, 5-1
audio, 1-25
audio devices, attaching, 3-8

B

battery pack
 battery-low warning, 2-8
 characteristics, 2-2
 charging, 2-4
 charging modes, 2-5
 checking the charge level, 2-6
 optimizing, 2-6
 taking care of, xi
brightness
 adjusting, 1-11

C

caring for your computer, ix
CD-ROM
 booting from, 5-16
CD-ROM drive tray
 ejecting, 1-17
cleaning your computer, xii
connecting your computer, xvii
contrast
 adjusting, 1-11

D

display
 automatic dim, 2-11
 opening and closing, 1-5
 power management, 1-4
 simultaneous, 1-4
 switching, 1-12
 video performance, 1-4

E

embedded keypad, 1-9
error messages, 6-7
external floppy drive
 connecting, 1-18
external keyboard, attaching, 3-3
external keypad, attaching, 3-4
external microphone,
 attaching, 3-8
external pointing device,
 attaching, 3-5
external speakers, attaching, 3-8

F

FAQ (Frequently Asked Questions), 6-2
fax/data modem, 1-20
features, 1-2
 connectivity, 1-3
 design and ergonomics, 1-3
 expansion, 1-3
 multimedia, 1-2

Index

performance, 1-2

H

hard disk, 1-17

installing, 3-16

help

online, accessing, xix

online, web, xix

hibernation mode

entering, 2-12

exiting, 2-13

hot keys, 1-11

activating and using, 1-13

exiting pop-up icons and
screens, 1-13

help, 1-11

I

indicator lights, 1-6

L

lock keys, 1-8

light green mode

entering, 2-16

exiting, 2-16

M

memory

installing, 3-14

modem

setting location, 6-5

monitor, attaching, 3-2

O

option

additional memory, 3-14

audio, 3-8

external keyboard, 3-3

external keypad, 3-4

external pointing device, 3-5

file transfer cable, 3-13

hard disk upgrade, 3-16

monitor, 3-2

Parallel cable, 3-12

PC Cards, 3-9

printer, 3-7

PS/2 y-bridge cable, 3-12

Universal Serial Bus, 3-10

P

palm rest, 1-14

passwords

changing, 1-29

power on, 1-27

removing, 1-29

setting, 1-27

setup, 1-27

PC Cards, 1-20

ejecting, 1-22

removing, 1-22

inserting, 1-21

Ports

location, 1-19

power management

heuristic, 2-10

power management modes

display standby mode, 2-11

hard disk standby mode,
2-11

- hibernation mode, 2-12
- light green mode, 2-16
- standby mode, 2-14
- printer, attaching, 3-7
- problems, *See* FAQ
(Frequently Asked
Questions)

S

- SafeOff, 5-10
- security
 - passwords, 1-26
 - security notch, 1-26
- service
 - when to call, xii
- Setup Utility, 5-11
 - Basic System Settings, 5-13
 - Load Default Settings, 5-25
 - Onboard Devices
 - Configuration, 5-18
 - Power Management
 - Settings, 5-23
 - Startup Configuration, 5-15
 - System Security, 5-20
- Sleep Manager, 5-2
 - functions, 5-6
 - taskbar icon, 5-3
 - troubleshooting space
 - allocation, 5-7
- specifications, A-1
- standby mode
 - entering, 2-14
 - exiting, 2-15
- support
 - worldwide, B-2

T

- touchpad, 1-15
 - turning on and off, 1-12
 - using, 1-15
- traveling
 - disconnecting your
 - computer, 4-2
 - moving around with your
 - computer, 4-3
 - setting up a home office, 4-5
 - taking the computer home,
 - 4-4
 - traveling internationally
 - with your computer, 4-8
 - traveling with your
 - computer, 4-6

U

- Universal Serial Bus, 3-10
 - enabling support, 5-17

V

- volume
 - adjusting, 1-12

W

- warranty
 - International Traveler s
 - Warranty (ITW), B-1
- Windows 95 keys, 1-10