

Chapter 1

Getting Started

Congratulations on your purchase of the award-winning AcerNote Nuovo notebook computer. Guaranteed and backed by Acer's world-class support, you can be sure of top-notch performance with your new AcerNote. This chapter guides you through the first few steps on setting up your notebook computer.

1.1 Item Checklist

Carefully unpack the carton and remove the contents. If any of the following items is missing or damaged, contact your dealer immediately.


- Notebook computer
- Accessory box
 - AC adapter
 - Battery pack
 - Floppy drive module
 - External floppy drive cable
 - User's manual and other documentation

Check for optional items, if any.


1.2 Taking Care of Your Computer

Your computer will serve you well if you take care of it. This section tells you how to care for the notebook. Also, re-read the important safety instructions at the beginning of this manual.

1.2.1 Notebook




- Do not expose the notebook to direct sunlight. Do not place near sources of heat, such as a radiator.




- Do not expose to temperatures below 0°C (32°F)


or




above 50°C (122°F).




- Do not subject the notebook to magnetic fields.




- Do not expose the notebook to rain or moisture.




- Do not spill water on the notebook.




- Do not subject the computer to heavy shock and vibration.



- Do not expose the notebook to dust and dirt.



- Never place objects on top of the notebook to avoid damaging the notebook.



- Never place the notebook on uneven surfaces.

1.2.2 AC Adapter

The AC adapter provides uninterrupted power to your notebook and charges your battery pack. Here are some ways of taking care of your AC adapter.

- Do not connect the adapter to any other device.
- Do not step on the power cord or place heavy objects on top of it. Carefully route the power cord and any cables away from personal traffic.
- When unplugging the power cord, pull on the plug and not on the cord itself.

1.2.3 Battery Pack

The long-lasting Lithium-Ion (Li-Ion) rechargeable battery pack gives you power on-the-go. Here are some things to keep in mind regarding your battery pack.

Caution:

- Replace the battery pack with the same type (Model Name: BTP-S31)
- Battery pack is suitable for use only with this notebook model
- Burn hazard. Do not disassemble. Handle damaged or leaking lithium-ion battery with extreme care. If the battery is damaged, electrolyte may leak from the cells and may cause personal injury.
- There may be local restrictions on the disposal or recycling of batteries; consult your local regulations or waste disposal provider.
- Do not expose to high temperatures (50°C / 122°F)

1.2.4 Cleaning and Servicing

When cleaning the notebook, follow these steps:

1. Close the display lid to turn the notebook off.
2. Disconnect the AC adapter.
3. Remove the battery pack.
4. Use a soft cloth moistened with water. Do not use liquid or aerosol cleaners.

Contact your dealer or see your service technician if any of the following occurs:

- Notebook has been dropped or damaged.
- Liquid has been spilled into the product.
- The notebook does not operate normally.

See section 7.3 for contact information.

1.2.5 Diskettes

Following are some tips on diskette management:

- Always make backup copies of diskettes that contain important data or program files.
- Keep diskettes away from magnetic fields and sources of heat.
- Avoid removing a diskette from a drive when the floppy drive activity light is on.

- Write-protect your diskettes to prevent accidental erasure. To do this, slide the write-protect tab to the write-protect position.





Figure 1-1 Write-protecting a 3.5-inch Diskette

- When you put a label on a 3.5-inch diskette, make sure that the label is properly attached (flat on the surface) and within the labelling area (area with slight surface depression) on the diskette. An improperly attached label may cause a diskette to get stuck in the drive when you are inserting or removing it.


1.3 Connecting the Notebook

After reading through the previous section, you are now ready to experience your new notebook. Connecting the notebook is as easy as 1-2-3.




Inserting the Battery Pack

Insert the battery pack into the battery compartment and slide the battery compartment cover in place.



Connecting the AC Adapter

Connect one end of the AC adapter to the DC-in port on the notebook's rear panel and the other end to a properly grounded power outlet.



Turning on the Power

Slide the display cover latch to the right and open the display to turn on the power.

1.4 Creating Backup and Startup Diskettes

Entering User Information

When Windows 95 loads for the first time, enter your user information. Have your Windows 95 authentication number ready, found in the Windows 95 documentation package.

Creating Backup and Startup Diskettes

Windows 95 prompts you to create backup and startup diskettes.



If your Windows 95 package contains a Windows 95 CD-ROM, you do not need to create backup diskettes for Windows 95. However, you may need to create the Windows 95 startup disk.

At this point, you need to create the notebook backup disk which allows you to boot-up your notebook from the floppy drive and access the CD-ROM drive for Windows 95 and driver re-installation in case of a hard disk crash (when the hard disk is not functioning properly and cannot be accessed) or when your system cannot startup Windows 95. See the backup kit for details.

If you do not wish to perform the backup at this time, you can skip through this step during Windows 95 setup. Access the Create System Disk tool when you wish to do so. However, we suggest you create the disk(s) as soon as possible.

1.5 Getting Help Online

This user's manual provides clear and concise information about the notebook, so read it thoroughly. To provide you with help when traveling, the notebook has a comprehensive online help.

Accessing Online Help

Follow these steps to access the online documentation:

1. Press the Windows logo button or Click on the Start button.
2. Select Programs.
3. Click on AcerNote Nuovo.
4. Select Online Help.

The online help is easy to navigate with hypertext and hypergraphics. Clear illustrations help describe notebook operation as well.

Getting Online

If you are connected to the Internet and have World Wide Web access, visit our home page (<http://www.acer.com/>) and get the latest information about our products, as well as updates on software drivers and utilities.